HOWARD WRIGHT

# PACIFIC SHOWER-BATHING TROLLEY CLEANING INSTRUCTIONS

# CAUTION

### Before cleaning:

- Unplug the power cord from the mains supply
- Depress the castor pedals into the Brake position

### During cleaning:

- Do not use abrasive cleaning products
- Do not use a water temperature of more than 50°C (122°F)
- Do not use excess water
- Do not use a steam cleaner, washing tunnel, high-pressure spray or hose
- Do not immerse the product in water
- Do not clean or degrease the steel shafts of the actuators
- Use only approved cleaning products. If bleach is necessary strictly adhere to the BLEACH CLEANING instructions
- Keep sharp objects such as razors etc away from the tub top
- Do not use oil based products
- Do not unplug the handset or actuators from the control box for cleaning

# **BLEACH CLEANING INSTRUCTIONS**

If none of the approved cleaning products provide the disinfectant level required then use a solution of Sodium Hypochlorite diluted to 1000ppm.

Bleach products are corrosive and degrading in nature and may cause damage to your product. If bleach is used, measures must be taken to ensure the product is rinsed thoroughly with clean water and thoroughly dried. Failure to rinse and dry the product will leave a corrosive residue on the surface possibly causing corrosion.

Failure to follow the above directions may void the product's warranty.

## **APPROVED CLEANING PRODUCTS**

Please refer to <u>www.howardwrightcares.co.uk</u> for approved cleaning products and maximum concentration.

### To wash:

ALL SURFACES

- Raise the tub sides to full height (fabric is taut)
- Ensure the free end of the drain hose is placed in a drainage area
- Flush the whole surface with fresh warm water (less than 50°C, 122°F)
- Wipe bogie and frame with a sponge or soft cloth wetted with warm water containing soap or mild detergent

# To dry:

- Leave the tub sides raised to drain and dry
- Wipe dry with a clean, soft cloth or sponge
- Lower tub sides after drying is complete

### To disinfect:

- Wash the surface
- Wipe the surface with a soft cloth or sponge wetted with an approved cleaning product
- Wipe off residue with water using a soft cloth or sponge
- Thoroughly dry

### REMEMBER

The upholstered top has a bielastic backing fabric with a polyurethane top coating. Soap residue left on the tub surface can degrade the surface. Therefore care should be taken to flush away all residual soap after use. Failure to follow these recommendations may lead to fabric failure.

Howard Wright Limited has a policy of continuous product improvement and reserves the right to change product specifications without notice. Howard Wright Limited is certified to ISO 13485:2003.

© Howard Wright Limited, 2018